

DVR SYSTEM User's Manual

Manual Revision : Above version. 7.0
Release Date : June. 2006

Contents

Contents	2
Installing hardware and software	4
System requirements	4
Installing the video card in the PC	4
Installing the software	4
Main Screen	5
Overview of the live screen	5
System Information(SYS-INFO)	6
Update History	7
Message function	7
Controlling PTZ cameras	7
Power down mode	8
Saving Configuration File	9
Programming the DVR system [SETUP]	9
Standard settings	10
Recording	10
Schedule	16
Motion	19
Color Control	20
PAN/TILT setup	20
Control User Access	21
Back Up	22
WEBVA (IP Camera)	24
Search Screen	27
Overview of the playback screen	29
Search bar	29
Playback bar	30
Event filters	30
Date/time search	30
Zoom function	31
Views	31
Live view	31

Back Up	31
Smart Search	33
Bookmark	33
Network Connection [CLIENT]	34
Client software	34
Direct recording(Save)	35
Multi-server connections	35
Web Client	36
Searcher	36
Installing the alarm I/O card	37
POS function	38
Connecting the POS box	38
Setting up the POS box	39
Setup in the DVR software	40
Analyzing transaction data	41
AVI Backup	43

Installing hardware and software

System requirements

Operating system : Windows XP

Hard disk : Min. 200 GB for accident prevention certification

Number of drivers required and special hardware requirements :

Card Type	Hardware requirements	Driver
900P ~ 1000P	Celeron, 2.66GHz, 256MB RAM, 40GB HDD	1 x video / 1 x audio
1500P	Celeron, 2.66GHz, 256MB RAM, 120GB HDD	2 x video / 2 x audio
2400P	Pentium 4, 2.66GHz, 256MB RAM, 120GB HDD	4 x video / 4 x audio
4900P	Pentium 4, 2.66GHz, 256MB DDR-RAM, 200GB HDD	1 x video / 1 x audio
9100P ~ 9400P	Pentium 4, 2.8GHz, 512MB DDR-RAM, 200GB HDD	1 x video / 1 x audio

Installing the DVR capture card in the PC

1. Turn the PC off and un-plug the main power cord. Open the PC and insert the DVR card in a free PCI slot.
You may have to remove the blank on the rear of the PC. Secure the card using a screw.
Connect the watchdog cable correctly to the recorder card and the PC (PC reset switch) but not required.
2. Close the PC cabinet and turn the PC on. Windows starts hardware recognition and detects the newly fitted DVR card.

IMPORTANT : Install the hardware and drivers before the software installation.

Installing the software

The S/W contains the following applications : DVR Server software

DVR Client

DVR Searcher

Before installing the software, make the following setting on the PC :

1. Set the screen resolution to 1024 X 768 pixels, True Color 32 bit.
2. If the graphic card uses an overlay function, disable the function.
3. Disable the screensaver under [Control Panel / Display / Screensaver].
4. Disable the "Energy Management". Set [Turn off monitor], [Turn off hard disks], [Standby] and [System standby] to "Never".

Main Screen

Overview of the live screen

After the software starts, an information window opens on the screen. Close it by clicking [OK].

- Setup: Allows you to configure the DVR system. Besides general settings, you can configure the followings : recording type, schedule, motion detection, pan/tilt function, network and backups.
- Search: To play back recorded video data. You have a wide range of options for finding, analyzing and saving relevant video data.
- Pan/Tilt: For controlling connected P/T/Z cameras.
- Function: Useful functions such as preview, system info, history, network messages or auto-email are available.
- Date/time: Display of date and time

On-screen information: In the live view, various information can be displayed with the video picture



Channel number



Recording of motion event



Normal (continuous) recording



Recording of sensor alarm event



Pre (Pr) or Post (Af)-event recording



Voice recording


Channel selector: Here you can select a specific channel or automatic channel sequencing.

- Main Screen: (live video) To view video pictures live, you can select either a single picture (full-screen) or up to 16 pictures at once (depending on your video card). You can move the channels around in the live-video area according to your needs. To do this, left-click a live video picture and keep the mouse button pressed. Now drag the video picture to the desired live video area and drop it there.
- Alarm outputs: Outputs 1-4 can be switched here manually (optional alarm I/O card required ; see the section “Installing the alarm I/O card” for fitting).
- Exit: Button for exiting the digital surveillance system.
- Screen Division: The video section of the live screen can be divided into 4,6,7,9,10,13 or 16 smaller screens. The channels can be swapped around on the screen. To move a channel, left-click it and keep the left mouse button pressed. Drag the video picture to the desired position and drop it there. If you left-click a channel, you can change it to full-screen display. Click again to return to the original view. A right-click enlarges the video area a fill the whole screen.

Main Screen

Preview: The preview shows all channels that are currently recording.

System Information: Provides information on operating system, program version or system hardware. Other useful tools are the Disk Space calculator, drive info or the frame-rate calculator.
(SYS-INFO)



Disk Space calculator


With this calculator, the recording duration can be roughly calculated for a known memory capacity. All recording, resolution and quality settings are taken into account. The upper window shows the probable recording duration after the hard-disk size is selected.

Disk Info

Click the button to display information on the total space, used space and free space of the current recording disk in a window.

Calculate Frame rate

This program calculates the compression rate and single-frame size of individual channels.



First select a camera or channel. Click [Start Compress data] to start the calculation. When the calculation is complete, you can display the picture size and compression with the different Codec variants on the screen. To do this, press [See the screen]. The number of pictures used for the calculation can be changed on the right of the [Start Compress data] button.

Main Screen

Update History : The history log contains the functions used by the system.

Message function

This function permits the sending of network messages to connected Network users. Enable a message and select a connected user.
Click [Send] to send the message.



Main Screen

Controlling PTZ cameras

To open the PTZ control tab, click [PAN/TILT] in the live screen. With the digital surveillance system, you can control a large number of PTZ cameras. You first have to configure a connected PTZ camera on the [Setup / PAN/TILT] tab.

Speed

The pan and tilt speeds can be adjusted according to requirements.

Zoom/Focus


You can zoom and focus the camera manually with the [+] and [-] buttons.

Control

This contains the direction control buttons. At the center an autofocus button is displayed (not active for all cameras).

Setup Preset

Under [Preset], you can save and retrieve camera positions. Up to 64 preset positions can be saved for each camera channel. Select a number from the Preset list and name this position under [ID]. Now move the camera to the desired position and then click [Save ID]. remove a preset with [Delete Preset].



Setup menu

Here you can control various functions of the PTZ camera. These functions cannot be accessed for all camera models.


Close

Click this blue button to close camera control.

Auto Group

This figure shows the Auto Group window.

Here you can form a group of preset positions. The positions of this group are then automatically set by this camera at specific successive time intervals. Enter a group number and ID and click [Group Add]. In the lower half, select a preset and click [Preset Add]. Add all desired positions to the group. Then click [Group Run] to start automatic positioning. At the bottom, you can set the movement speed and the dwell time for each position.



Main Screen

Power down mode

After you click the “Power down” icon on the GUI, the following window is displayed.

You now have the following options :



The software and the PC are completely shut down.




Press to change user.



Reboot the system.



Go to Windows mode.




Click to cancel.



Saving Configuration File

This function allows you to save the complete configuration of the DVR system and reactivate it when required. Under [Setup], click [Manage the text file of setting value...] at the bottom of the setup screen.



Click the [Write...] button to save the configuration file of the system. The file name extension is “*.sat”. Enter a file name and click “Save”. The configuration is not saved.

You can load a configuration file by clicking [read...].

Programming the DVR system [SETUP]

Via [Setup] in the live screen, you open the configuration menu of the digital surveillance system. You can save your settings by clicking [Save]. Click [Apply] to save your settings and exit Setup. In Setup, you can set the following functions:

Standard settings

The screenshot shows the 'Standard' settings tab in the DVR system setup interface. The top navigation bar includes: Standard | Recording Type | Schedule | Motion | Color Control | PAN/TILT | Control User Access | Back Up. The main settings area is divided into several sections:

- General Settings:** Includes checkboxes for 'Camera name' and 'See the Voice Wave'. Buttons for 'Add Printer' and 'Time Setup' are located to the right.
- Camera Auto Switching:** A section with a 'Switching every' field set to '5' and a unit of 'Sec'.
- Auto System reset:** A section with a checkbox for 'Auto System reset', a frequency of '1 day(s)', a time of '1:00:00 AM', and a 'Reboot' button.
- Compression:** Includes a 'Picture Quality' dropdown set to 'MJPEG' and a 'Resolution' dropdown set to '320x240'. A 'Set Password' button is at the bottom of this section.
- Managing Disk:** Includes buttons for 'Scan Disk', 'Format', and 'Refresh DataBase'. A dropdown menu shows 'D'. A checkbox 'Record while data is deleted' is checked.
- Set Channel:** Radio buttons for '4 CH', '8 CH', and '16 CH', with '16 CH' selected.
- Other Buttons:** 'Setting Day Light Saving...' and 'DX setting...' buttons are located below the channel settings.
- Windows Logon:** A button located at the bottom right of the main settings area.

The bottom of the window features a bar with the following buttons: 'Manage the text file of setting value...', 'On screen keyboard', 'Apply', 'Cancel', and 'Save'.

Voice

One channel is provided for recording audio data. The built-in sound card of the PC is used as input. Click here to activate audio input (voice recording). Select between microphone(MIC) or line-in(LINE).

Monitor out

The video card of the digital surveillance system has a socket for connecting an external monitor (Chinch connector next to the camera inputs). You can select channels for display on the external monitor by clicking [Monitor out Select] (not High End Model). The display mode in the surveillance system (single-picture, multi-channel display) is used for the external connection. In the case of single-picture display, the channels can be shown in sequence. You can define the display time (dwell time) of each channel by entering the time in seconds.

Programming the DVR system [SETUP]

Add Printer

Click to install a printer. You can connect a local or network printer to the surveillance system. You install the printer via the Windows standard routine.

Time Setup

For setting the current system time.

IMPORTANT : If you reset the clock, older video data may be overwritten.

Auto System reset

Reboot the recording system automatically. If necessary, you can merely switch off the system (without rebooting).

Disk Manager

The disk manager includes functions for defining, checking and formatting a disk drive. From the menu, you can select a drive letter for saving data(e.g., drive D). When all space is used up on this drive, the system automatically goes to the next available drive letter.

[Scan Disk] checks the drive for errors. Click [Format] to delete all data from the drive via the Windows formatting function.

IMPORTANT : If only one partition is available for saving data (e.g., C:\), the data is written to this drive. In this case, the [Format] function must be carried out only once.

Click [Refresh Data Base] to check the structure of recorded data of the individual channels and reorganize it Automatically if necessary.

Enable [Recording while delete data] for continuous saving of recorded data. When the drive is full, the oldest data is automatically overwritten. If this function is not enabled and no further memory is available, an alarm tone sounds and a message appears, telling you to change the storage location.

Compression

Here you can set the compression type, the recording resolution and the recording quality.

Three compression methods are available for recorded video data : MJPEG, MPEG4 or MPEG4+

Three resolution are provided for video pictures : 320 X 240, 720 X 240 or 720 X 480 pixels

Programming the DVR system [SETUP]

Click [Picture Quality] to select the compression rate. The higher the compression rate, the lower the memory Requirement, but the poorer the image quality.

For MPEG4+ compression, the sensitivity of the motion sensor must be set and the noise filter must be set.

Windows logon

Enter a user name and password for a Windows logon. You need these for an automatic system start.

The data is automatically accepted by the operating system.

Power Down mode

When you switch off the digital surveillance system, the PC either returns to Windows or shuts down.

Camera name


Enable this option to display the name, number and status of each camera in the video picture.

On-screen keyboard

For entering camera names, passwords, etc., an on-screen keyboard is provided. You operate the keyboard with the mouse. No external keyboard is required, which increases access protection.

Password


The 3 areas (for primary password, user setup [Setup/Standard] and network user setting [Setup/Network]) are now combined in a single password manager under [Setup/Standard /Set Password]. The password manager now looks like this :



Programming the DVR system [SETUP]

To install a user :

1. First click [Add] on the left or right-click the left of the screen.



2. Select a user group type : Super User, Power User, User, Guest.

The user groups have different user permissions.

You can change these permissions at any time later.

3. Enter a user name, a password and the password confirmation. Click [Apply].

4. The following table shows the different user permissions.

Set the check-mark to use a permission.

Permission	Meaning
Standard	Permission for [Setup / Standard] menu item
Recording Type	Permission for [Setup / Record] menu item
Color Control	Permission for [Setup / Color control] menu item
Motion	Permission for [Setup / Motion] menu item
Network Setup/Network	Permission for [Setup / Network] menu item
Pan/Tilt	Permission for [Setup / Pan/Tilt] menu item
Schedule	Permission for [Setup / Schedule] menu item
Search/Search	Permission for access to search screen
Power down	Permission for switching off system
Backup	Permission for [Setup / Backup] menu item
History	Permission for [Setup / History] menu item
Web Camera / Web Camera	Permission for [Setup / Web Camera] menu item
Set Camera	Enabled cameras are visible to the user.

Select the permissions required for the user and then click [Save] and [Close].

For every system access, whether direct at the PC or using client software / web client ,
a valid user name and password now have to be entered.

Set Channel

The administrator can configure the video card used (4,8 or 16) to the software of the digital surveillance system. If channels are not used, they have to be deactivated under [Setup / Recording Type].

Programming the DVR system [SETUP]

Day-light savings


Here you can set the day-light savings. The DVR then is switching automatically the summer and winter time.

DX-Setup

In the Standard tap of SETUP, you can see the new button of DX Setting.

The DX setting is used to adapt the VGA card to the surveillance system. There are 2 display modes Available : 1. Primary mode, 2. Overlay mode.

The software detects the best display mode automatically.
On display errors please activate the primary mode.




The RGB-function improves the primary mode, but this consumes more CPU power.
In RGB mode you can set a better picture quality (32 Bit).

Dual Monitor

The dual-monitor function allows you to connect a secondary monitor. To make this possible, a graphic card with 2 monitor outputs must be installed in the system. In the Windows display properties, the secondary monitor output must be enabled – i.e., the Windows desktop must be extended to the secondary monitor. For further questions on enabling the secondary monitor output on your graphics card, contact the graphics card manufacturer.

Functions:

1. If a graphic card with 2 monitor outputs is installed in the system, you can now enable the dual-monitor function in the Software under [Setup / Standard]



IMPORTANT : If no graphic card with 2 monitor outputs in installed but the Dual-Monitor function is enabled, you may have problems with display and stability.

2. Following activation, the channels are displayed as on the main monitor (e.g.,quad view).

You can still choose between different views.

3. If necessary, you can click the Minimize button to minimize the view on the secondary monitor.

Click the dual-monitor icon on the main monitor to restore the original view on the secondary monitor.

4. To hide the toolbars, right-click while the mouse to restore the original view on the secondary monitor area.

Click again to restore the view.


Programming the DVR system [SETUP]

5. The dual-monitor function now offers you a further feature in the event of anything happening. If an event occurs (motion, alarm,...), the corresponding channel can be shown full-screen on the secondary monitor.

Under [Setup / Record / Event setup], select “Print by Second monitor”.

The corresponding channel is now shown full-screen on the secondary monitor but not full-screen on the main monitor.

6. Click the [Change Primary Secondary] button in the [Setup / Standard] button in the [Setup / Standard] menu to switch between the main monitor and the secondary monitor if required.



Programming the DVR system [SETUP]

Recording

Camera			Recording Type				Sensor type	Alarm Control								
NO	Display	Position	Event	Frame (1-30)	Pre	Post		Time	1	2	3	4	5	6	7	8
1	OK		Motion	max/max/max	0	0	0	0	-	-	-	-	-	-	-	-
2	OK		Motion	max/max/max	0	0	0	0	-	-	-	-	-	-	-	-
3	OK		Motion	max/max/max	0	0	0	0	-	-	-	-	-	-	-	-
4	OK		Motion	max/max/max	0	0	0	0	-	-	-	-	-	-	-	-
5	OK		Motion	max/max/max	0	0	0	0	-	-	-	-	-	-	-	-
6	OK		Motion	max/max/max	0	0	0	0	-	-	-	-	-	-	-	-
7	OK		Motion	max/max/max	0	0	0	0	-	-	-	-	-	-	-	-
8	OK		Motion	max/max/max	0	0	0	0	-	-	-	-	-	-	-	-
9	OK		Motion	max/max/max	0	0	0	0	-	-	-	-	-	-	-	-
10	OK		Motion	max/max/max	0	0	0	0	-	-	-	-	-	-	-	-
11	OK		Motion	max/max/max	0	0	0	0	-	-	-	-	-	-	-	-
12	OK		Motion	max/max/max	0	0	0	0	-	-	-	-	-	-	-	-
13	OK		Motion	max/max/max	0	0	0	0	-	-	-	-	-	-	-	-
14	OK		Motion	max/max/max	0	0	0	0	-	-	-	-	-	-	-	-
15	OK		Motion	max/max/max	0	0	0	0	-	-	-	-	-	-	-	-
16	OK		Motion	max/max/max	0	0	0	0	-	-	-	-	-	-	-	-

☐ Record Motion/Sensor Event

Auto Camera Search Event setup Set up Audio Set ALARM Event>>

Manage the text file of setting value... On screen keyboard Apply Cancel Save

Video signal

You can show or hide a connected camera on the live screen. Although an installed but hidden camera is not shown in the live view, it is recorded with the corresponding setting. Left-click a channel field to switch between options.

Name

You can give each camera input a name. This camera name is shown in the video picture and saved with it. You can enter the name via a normal keyboard or the on-screen keyboard.

Recording type

The following recording types are available:

- Record: [continuous recording] The video data is recorded continuously.
- Motion: [motion-triggered recording] Recording is triggered by motion sensors of the respective channel. You can configure the sensors under [Setup/Motion]. They react to changes in the video picture (or parts thereof).

Programming the DVR system [SETUP]

- Sensor: [recording triggered by alarm sensor] Recording is controlled via max. 16 alarm inputs. The input connections are on a separate sensor card, which has to be built in to the system. If you click the record type button again, another button appears on the right.

Event	Frame (1-30)
Sensor	max/max/max
Motion	max/max/max

Click this button to open a submenu. You can now choose the alarm inputs to which the selected channel is to react. Do this by enabling the required alarm inputs(1–16).

- Schedule: [scheduled recording] Recording takes place according to a channel-specific schedule. You can select a different recording type for every hour. You define the schedule under [Setup/Schedule]
- Rec/Mot: [continuous recording/motion sensor] The video picture of the channel is recorded continuously and for motion sensor events in this channel.
- Rec/Sen: [continuous recording/alarm sensor] The video picture of the channel is recorded continuously and on the triggering of the respective alarm input.
- Mot/sen: [motion/alarm sensor] The video picture of the channel is recorded if either the motion sensor or the alarm sensor is triggered for this channel.
- R/M/S: [record/motion/sensor] The video picture is recorded continuously and if either the motion sensor or the alarm sensor is triggered for this channel.
- No Record: No video data is recorded this camera input.

Frame

Here you define the frame rate (number of pictures recorded per second) for the channels. In the NTSC standard, this is max. 30 frames per second. The frame rate can be variably defined, but the maximum recording frame rate must not be exceeded.

Furthermore, for the motion sensor and alarm sensor recording types, the frame rates can be set separately for pre- and post-event recording.

Programming the DVR system [SETUP]

Pre- and post- event recording [Pre/Post]

We have a so-called pre- and post-event recording feature. If recording is triggered by a motion or alarm sensor, the system stores the video data of up to 20 minutes before and after the event. The pre-event recording data is buffered for the time specified and retrieved if required (if an event occurs). The pre- and post-event recording times can be set at anything between 1 second and 20 minutes.

IMPORTANT : The pre-recording first functions following the expiry of the desired time after setting, since otherwise the data is not written completely to the buffer.

Sensor type

Defines the switch type of the alarm inputs. It is either NO (normal open) or NC (normal close). If you select Two or more alarm inputs for triggering recording under [Set ALARM Event], this switch setting applies to all Alarm inputs.

Alarm Control

The recording system can switch up to 8 alarm outputs for different events. The connections are on an optional alarm card, which has to be built in to the system. Here you can define the alarm output to be switched for an event. Possible events are motion detection, triggered of an alarm input, loss of video signal and active Recording status. The duration of the activation of the alarm output can be set between 0 and 90 seconds. If this is set to [on], a short impulse is activated at the output.

Auto Camera Search



Click to search automatically for connected video sources. Sources found are activated for live display and set to continuous recording.

Event setup

Here you can activate a function that points to any event that occurs. Two functions are available. The first function switches to full-screen display for a specific time if an event occurs. The second function can control a dome camera if an event occur.

Set ALARM Event

Here you can forward a video signal loss and the recording state to an alarm output.




Programming the DVR system [SETUP]

Record Motion/Sensor Event

If you enable this function, the event is registered on the playback screen under Function/Event filter/Event memory/log.

Setup Audio



Here you can use 16Ch. Audio with DVR model 9100 ~ 9400(Real Time Board).

This button is only shown when you choose the option for audio while installing S/W.

You can select each audio source number by each camera number one by one.

With [Set internal sound card] function, you can choose audio input type from main-board and can control audio volume for recording and displaying.

With [Volume] button, you can control the volume from the PC system.

If you don't want the system be muted, please use the feature "System Speaker On".

Programming the DVR system [SETUP]

Schedule

In the schedule, you can select a different recording type for each hour and camera. Mark a period and click a recording type button in the lower part of the window. If you right-click the mark, you can also switch between recording types.

Standard | Recording Type | **Schedule** | Motion | Color Control | PAN/TILT | Control User Access | Back Up

Camera position: CH 1

Camera

	SUN	MON	TUE	WED	THU	FRI	SAT
00:00	-	-	-	-	-	-	-
01:00	-	-	-	-	-	-	-
02:00	-	-	-	-	-	-	-
03:00	-	-	-	-	-	-	-
04:00	-	-	-	-	-	-	-
05:00	-	-	-	-	-	-	-
06:00	-	-	-	-	-	-	-
07:00	-	-	-	-	-	-	-
08:00	-	-	-	-	-	-	-
09:00	-	-	-	-	-	-	-
10:00	-	-	-	-	-	-	-
11:00	-	-	-	-	-	-	-
12:00	-	-	-	-	-	-	-
13:00	-	-	-	-	-	-	-
14:00	-	-	-	-	-	-	-
15:00	-	-	-	-	-	-	-
16:00	-	-	-	-	-	-	-
17:00	-	-	-	-	-	-	-
18:00	-	-	-	-	-	-	-
19:00	-	-	-	-	-	-	-
20:00	-	-	-	-	-	-	-
21:00	-	-	-	-	-	-	-
22:00	-	-	-	-	-	-	-
23:00	-	-	-	-	-	-	-

camera 1 ☒ camera 2 ☐ camera 3 ☐ camera 4 ☐ camera 5 ☐ camera 6 ☐ camera 7 ☐ camera 8 ☐ camera 9 ☐ camera 10 ☐ camera 11 ☐ camera 12 ☐ camera 13 ☐ camera 14 ☐ camera 15 ☐ camera 16 ☐


Record Sensor Motion Rec/Sen Rec/Mot Mot/Sen R/M/S Cancel

On screen keyboard Save Apply

Programming the DVR system [SETUP]

Motion


For motion-triggered recording, the motion sensors for the different cameras have to be configured. Select a camera and mark the areas in the camera window to be monitored. With the Sensitivity slider, you define how big the changes in the video picture have to be to trigger motion detection. Click [Delete] to delete a marked area. Enable [Beep for Motion] for an acoustic signal and [Show Motion Area] for an optical marking if motion is detected. Select [To the maximum quality after Motion/Sensor] for recording at maximum frame rate following an event.



Color Control


Here you can set the brightness, saturation, contrast and hue of the channels. If you click [Setup User's Default], the settings for this channel are used. [Cancel User's Default] resets all settings to the default system values. [All Default Color] sets the values of all channels to the user setting. [Default Color] sets the settings to the user definitions.

Programming the DVR system [SETUP]



PAN/TILT (dome camera) setup

With the digital surveillance system, you can control pan/tilt cameras. First select the camera channel to which a dome camera is connected. Then select the connected model(protocol) with the device number.



Programming the DVR system [SETUP]

You also have to set the communication parameters between the system and the dome camera correctly (COM port no. on system, speed, data bits, parity).

User settings

If your dome camera is not on the model list, you can enter the specific control commands here(hex code).

Master Controller

Here you can integrate a separate camera master controlled into the system. Select the model from the list, set the communication parameters, and activate the device.

Control User Access

You can have remote access to the digital surveillance system via a network. The system then works as a server. A user accessing this server is called a client.

TCP/IP

To enable remote access, click [TCP/IP].

Check IP

The server IP is defined either automatically or manually.

Port

Define the network port here. The default setting is Port 2000. The server and client port numbers must be identical.

Programming the DVR system [SETUP]

Transmission speed and image quality

Select a quality or speed according to the connected network.

User


Here you can add or delete network users. To add a user, define the user ID and password, confirm the password and click [Add]. You can remove a user with [Delete].

Connected Client List

Click to view all active connections.

Web Server

The digital surveillance system has a built-in web server that allows access to the system via the Internet Explorer. The user can access the system by entering the IP address in the address bar of the Internet Explorer.



Under [Settings], you enter the setup of the web server. This is active following system installation. If necessary, the port of the web server can be changed under [Server Port].

Voice communication

Voice communication is possible between server and client. Enable communication and select a connected user. The microphone is connected to the line-in port of the PC. The voice recording function and [Setup/Standard/Voice] must not be enabled.

Setup TCP/IP

Here you can make settings for the TCP/IP protocol. You can define this data automatically or manually, depending on the network connection. For manual definition, enter the IP address, the subnet mask, the gateway, and the DNS of the network adapter in the respective fields. If you use a router, enter a local IP and user the router IP as gateway and DNS.

Programming the DVR system [SETUP]

Emergency Call

With this function, an emergency call can be made to a telephone number if an event such as an alarm occurs. For this you need a voice model integrated in the system. For an own emergency call please overwrite the file with an own file.


IP server

Via the IP server function, the IP can also be linked to any site name.

Back Up

Here you can define the making of backups. The data can either be backed up in database format or an an AVI file. In database format, the data can only be edited on this system or with the special software(Searcher) supplied. As an AVI file, the video data can be displayed with programs such as the Windows Media Player.


First select the channel whose data you want to back up. In the window below, select a period. Click [Backup] to save the data in database format. Click [Make AVI...] for AVI conversion.



Programming the DVR system [SETUP]

Make AVI

If you click [Make AVI..], the AVI converter opens. Select a period under [Data]. Click [Save File..] and enter a file name. Confirm with [Save]. In the center of the AVI converter, you can restrict the period for which an AVI file is generated. Click [Insert Water Mark] to assign a digital watermark to each AVI file. Click [Go!] to start The conversion process.



Backup disk

Click to select the path for the backup data.

Run NeroBurning...


Click to start the Nero CD burn application automatically (if installed on your system). The data is then backed up to an external storage medium.

Windows explorer.exe

Click to open the Windows Explorer for data management.

Send E-Mail

You can send a converted AVI file immediately as an e-mail. First create an AVI file. Then click [Send E-Mail]. A password entry window opens.



Programming the DVR system [SETUP]

Enter a title and brief description of the short film scene. The file name of the last generated AVI file appears automatically. On the next line, enter the SMTP server address of your e-mail provider.

Under [Mail Address], enter your own address (From) and the destination address (To). Click [OK] to send the e-mail.

IMPORTANT : Make sure the recipient's mailbox has sufficient capacity.

Backup Schedule

Here you can define that a backup for a particular period is made at the specified time. First highlight a channel. And then select it by clicking [Channel]. Define the period you want to save under [Save time] and the backup time under [Back Up Time].

The screenshot shows the 'Backup Schedule' window with a table for configuring backup times for 16 channels. The table has columns for 'Save time' and 'Back Up time'. Channel 1 is selected with a checkmark.

	Save time	Back Up time
<input checked="" type="checkbox"/> 1	2003-05-15 23:00~2003-05-17 10:00	2003-05-15 23:00~2003-05-17 10:00
<input checked="" type="checkbox"/> 2	2003-04-26 18:50~2003-05-17 10:00	2003-04-26 18:50~2003-05-17 10:00
<input type="checkbox"/> 3	2003-05-16 02:02~2003-05-17 10:00	2003-05-16 02:02~2003-05-17 10:00
<input type="checkbox"/> 4	2003-05-15 23:00~2003-05-17 10:00	2003-05-15 23:00~2003-05-17 10:00
<input type="checkbox"/> 5	2003-05-17 10:26~2003-05-17 11:00	2003-05-17 10:26~2003-05-17 11:00
<input type="checkbox"/> 6	2003-05-17 10:59~2003-05-17 11:00	2003-05-17 10:59~2003-05-17 11:00
<input type="checkbox"/> 7	2003-05-17 10:26~2003-05-17 11:00	2003-05-17 10:26~2003-05-17 11:00
<input type="checkbox"/> 8	2003-05-17 10:59~2003-05-17 11:00	2003-05-17 10:59~2003-05-17 11:00
<input type="checkbox"/> 9	2003-05-17 10:26~2003-05-17 11:00	2003-05-17 10:26~2003-05-17 11:00
<input type="checkbox"/> 10	2003-05-17 10:59~2003-05-17 11:00	2003-05-17 10:59~2003-05-17 11:00
<input type="checkbox"/> 11	2003-05-17 10:26~2003-05-17 11:00	2003-05-17 10:26~2003-05-17 11:00
<input type="checkbox"/> 12	2003-05-17 10:59~2003-05-17 11:00	2003-05-17 10:59~2003-05-17 11:00
<input type="checkbox"/> 13	2003-05-17 10:26~2003-05-17 11:00	2003-05-17 10:26~2003-05-17 11:00
<input type="checkbox"/> 14	2003-05-17 10:59~2003-05-17 11:00	2003-05-17 10:59~2003-05-17 11:00
<input type="checkbox"/> 15	2003-05-17 10:26~2003-05-17 11:00	2003-05-17 10:26~2003-05-17 11:00
<input type="checkbox"/> 16	2003-05-17 10:59~2003-05-17 11:00	2003-05-17 10:59~2003-05-17 11:00

Buttons at the bottom: On screen keyboard, Save, Apply.

Confirm Backup

Here you can view backed-up data. On the left, select a channel and the backup section, and click the playback or stop button on the right.

The screenshot shows the 'Confirm Backup' window. On the left, there is a 'BackUp Data' section with a dropdown menu set to 'CH 1' and a list of backup times: '2003 04 26 13:10 ~ 13:19' and '2003 05 16 00:40 ~ 00:49'. On the right, there is a 'BACKUP CONFIRM' section with a video player interface showing a black screen and playback controls (play and stop buttons). Buttons at the bottom: On screen keyboard, Save, Apply.

Programming the DVR system [SETUP]

WEBVA (IP Camera)

This tap enables you to integrate network cameras.

Now only VIVOTEK IP camera is supported. (No Come control function)

An enabled web camera channel is connected to the respective BNC video input.


The number of channels (BNC+web cameras) cannot exceed the max. channel capacity of the PCI recording card.

The following figure shows the [Web Camera] menu. Open this menu by clicking the [setup] button.

You can select a channel for the incoming web camera signal.

Enter camera access data on the right (enabling, IP address, login, password, port).

At the bottom are options for transmission And storage type.



Using VA Camera : Set the check mark to use a web camera on this channel.

IP Address : Address or domain name of the web camera.

This address must be configured in the web camera or defined automatically by a DHCP server.

Login : The login name for administrator is required.

Password : Enter the administrator password.

Port : Enter the http port number used. This port must be configured in the web camera.

There are further options under the preview picture.



Capture : The web camera is shown on the live screen.

The recording is made in http mode at 1 frame per second.

You can delay data display on the screen. The camera is shown in the same way on the secondary monitor.

Programming the DVR system [SETUP]

Streaming : The web camera is shown on the live screen, with camera information at the top and bottom. No recording is made. The camera is not shown on the secondary monitor. The max. possible resolution is 320X240(352X288,PAL) pixels.

Capture + Streaming : The camera is shown on the live screen and on the secondary monitor. The camera signal is prepared for recording. Select the recording type under [Setup / Record] (e.g., motion-triggered recording). The same recording types as for analogue cameras are available. The max. possible resolution is 320X240(352X288,PAL) pixels.

Protocol : Select between UDP (no backup data), TCP (with backup data) and HTTP (single -frame mode, 1frame/sec)

Search Screen

Overview of the playback screen

Search bar:	This function gives you direct access to recorded video data. The data is displayed as a colored bar for each channel and according to recording type.
Channel selector:	Buttons for activating/deactivating channels for display in the video area. The channels are arranged automatically in the video area. For more than for video channels, you can access the other video channels via the vertical scroll bar to the right of the channel selector.
Playback bar:	Various functions are provided for playing back recorded data. In addition to continuous playback, you can select picture-by-picture display for analysing the video data.
Date/time:	Here you can go directly to pictures recorded on a specific date or at a specific time.
Video zoom:	For zooming parts of the video picture.
Functions:	Other playback screen functions such as backups or event search.
Exit:	Button for exiting the playback screen.

IMPORTANT : To switch to the Windows user interface, the switch-off mode must be set to “Window” under [Setup / Standard / Power Down mode].

Programming the DVR system [SEARCH]

Search bar

The search bar displays clearly all recorded video data as colored bars for each channel. Switches are provided on the left for displaying the desired channel in the video area. Four channels are shown at a time in the search bar. With the vertical scroll bar on the left, you can select other channels. If you check [Multi], the division of pictures is adapted automatically. If you click [All], all available channels are displayed with a corresponding picture division in the video area.

To select video data, left-click a time in the search bar. The currently selected time is marked by a vertical line. There are 3 different time divisions available in the search bar: 24 hours, half-hour and minute. You can switch between the time divisions by clicking the time bar label. With the horizontal slider at the bottom of the screen, you can also adjust the search time.

Playback bar

Three functions simplify playback of recorded video data. You can play back data continuously or frame by frame. You can also playback the video pictures forwards or backwards at different speeds. Click the loudspeaker button to switch off any recorded audio data.

Event filters

These functions enable you to search recorded video data for different event types. First click [Function] and then [Event].

The event memory (History) logs all events (date, time, camera number, event type). Click a line in the event memory(History). If you click [Search Area], the vertical line in the search bar jumps to this event and displays the respective video image. Click [Release all] to clear the event memory, or click [OK] to close it.

The event filter enables you to search for the following :

- Motion events (pink) via [MOTION]
- Alarm events (blue) via [SENSOR]
- Voice recordings via [AUDIO]
- All events via [ALL]
- Normal display (yellow) via [NORMAL]

The different events are displayed in corresponding colors in the search bar. Click the blue button at the top of the event filter to close it.

Programming the DVR system [SEARCH]

Date/time search

You can go directly to a time in the search bar. In the calendar, first select the year, month and date.

You can select the hour and minute with the up/down keys. The vertical line in the search bar automatically jumps to the set time.

Zoom function

Use the zoom function to enlarge the recorded video picture. First select a video channel by left-clicking the video area. You can now change the zoom area in the zoom window with the [+] and [-] buttons.

The enlarged picture is displayed in the video area. You can drag the zoom area by pressing and holding down the left mouse button.

Click the center button to return the video picture to its original state.

Views

As described earlier, the division of the video area adapts automatically to the number of channels selected in the search bar (1,4,9,16). If you left-click a video picture in the video area, it changes to single-picture display. If you right-click a video picture, the video area is enlarged to fill the screen; right-click again to return to normal.

Live view

Click [Live] to show all active channels.

Back Up

Click [Back Up] to use the data backup function.



Programming the DVR system [SEARCH]


Image Backup

With this function, you can save individual pictures as BMP, JPEG or YUV files. Click this button and select the storage location. Enter a file name and type. Click [Backup] to save the picture.

Make AVI

On the playback screen, you can generate AVI sequences for data processing. The difference from generating AVI files via [Setup/Backup] is that here you define only the start time in the video sequence, and you end conversion with [Stop saving AVI file], or else it stops when no more video data is available.


In the video area, click a channel to go into single-picture mode and mark a start time in the search bar. Click [Backup/Make AVI] to open the AVI converter of the playback screen.



Click [Save File...]. The [Save As] dialog box opens. You can accept the suggested file name for the video sequence by clicking [Save]. You can insert a description and a watermark. Click [Start] to start conversion. Click [Stop making AVI file] to stop at any time.

Print

Here you can print images from video recording or send them by e-mail. You can start [Backup/Print] from any video view. You can enter a title and comment for the image.



Click [OK] to print the image on a system printer. Click [Send E-Mail]

to send the image to an e-mail address. Enter the SMTP server, your e-mail address and a destination address in the respective fields. close the dialog box with [OK].

Programming the DVR system [SEARCH]

Smart Search


Use this function to search for changes in individual area. In the search bar, mark the start time for the search. Open the Smart Search dialog box via [FUNCTION] and [Smart Search].



Mark one or more search areas in the video picture and define the sensitivity. The higher the sensitivity, the smaller the changes that are registered. Click [Make AVI] to generate a video sequence of the pictures in which the image has changed. Only marked areas are taken into consideration. Use the control keys to play forwards or backward continuously or just to the next scene. Click [Print] to print individual pictures.

Bookmark

Bookmarks help you to find specific video sections in the recorded data. Go to the desired time in the search bar. Click [FUNCTION] and then [Bookmark]. Buttons appear for adding favorites and displaying a favorites list. click [Add Favorites], enter a name and confirm with [OK].



Click [Favorites list], select a favorite and click [Go] to access the saved bookmark.


Network Connection [CLIENT]

To connect the digital surveillance system to a network or the Internet, you need a physical connection via the LAN adapter or a modem.

Client Software


The Client software is used for remote monitoring of the server system via TCP/IP or modem. It provides the same scope of functions for analyzing recorded data as the server software. The client software is on the CD supplied and must first be installed. Select the Client software and run “setup.exe”. Follow the instructions on the screen and complete the installation correctly.

Start the client software by double-clicking the desktop icon. You are asked to disable the “True Color Rendering” function of the graphic card (no check mark set). Confirm with [OK].



The client software user interface and the connection dialog now open. You can choose between modem, TCP/IP or IP server connection. First enter a name for the connection.

For a LAN(Local Area Network) connection, select [TCP/IP] and specify the IP address of the destination server. for a server login, you have to enter [ID] and [Password] as registered in the DVR server under [setup / Network / User]. Click [Port] to change the communication port (default:2000). The port must be identical for the server and the client. You can edit a connection on the list with [Insert], [Delete] and [replace]. Now click [Connect] to start communication with the server.



Now click [Connect] and [OK] to start communication with the server or display pictures. For the transmitted data, you now have comprehensive search, analysis and control functions as in the server software.

Network Connection

Direct recording




An additional function for saving data on a client system is direct recording. You can save the data locally on the storage drive of the client PC by clicking [FUNCTION] and [Save].

You can access this data by clicking [Local Search]. Click [Remote Search] to access the data recorded on the server.

Multi-server connections

With the Client software, you can access several servers simultaneously. Up to 16 cameras at 16 locations can be displayed simultaneously. First, connect to the different servers. The [Select connected Server] tabs lists all connected server. Enable [Assign Multiserver]. Click [Set Camera]. With the mouse, drag a camera from the list on the right (server) to the list on the left (client). You can also save or load channel combinations. Click [OK] to open the video view.



Web Client

The DVR system integrates a so-called web-server. This provides data to the connected network via the HTTP Protocol. This enables you to access the DVR server via the Internet Explorer via the connected network. The Web-server is automatically loaded when the server starts.

Open the Internet Explorer of a PC connected to the network or the Internet. Enter the IP address or the Address registered via DynDNS in the address line and confirm your input. The web-server of the destination Server opens and you are asked to confirm the loading of a plug-in.

IMPORTANT : Your Windows setup may have various functions that prevent loading a plug-in (Firewall, Popup-blocker, Download Active X control elements not permitted.)

Enter the data of a user installed in the server program under [Setup / Network] to receive access to the web interface. The web interface opens.

IMPORTANT : If the selected user has access to all functions of the server program, he/she can make all server settings via this web interface. You should therefore protect the setup level from unauthorized access by using passwords.

Searcher

The Searcher is on the software CD. With this program, you can analyze recorded and saved surveillance data on any PC.

Run "setup.exe" for Searcher and follow the instructions on the screen and complete the installation correctly.


You are asked to specify a path containing the saved data. Confirm with [OK].

The Searcher user interface contains all functions of the playback screen. You can search for data, print pictures, make AVI files or save pictures, etc.

Installing the alarm I/O card

The I/O card (optional) enables you to connect up to 16 sensors to the surveillance system. The I/O card also has 8 relay outputs for connection external equipment.

The I/O card needs 2 PCI sockets in your PC.



Switch the PC off and pull the main plug out. Open the PC cabinet. Connect the sensor card with the alarm card via connectors 2 and 3. Use the short flat cable provided.

Connect the recorder card to the sensor card (connector 1) using the second flat cable.

Now plug the sensor card into a free PCI socket and the alarm card into any free socket.

Please use the provided power connector to connect the sensor card with the power supply of the PC.

Close the PC cabinet and switch the PC on.

The pin connections of the alarm and sensor card is shown on the alarm card.

Alarm card	Sensor card
NO8	GND
COM8	GND
NO7	GND
COM7	GND
NO6	16
COM6	15
NO5	14
COM5	13
NO4	12
COM4	11
NC4	10
NO3	09
COM3	08
NC3	07
NO2	06
COM2	05
NC2	04
NO1	03
COM1	02
NC1	01

Alarm card :

Up to 8 outputs (24V DC,1A) can be connected ;
1-4 can be switched to NO(Normal Open) and
NC(Normal Close) and 5-8 only to NO.


Sensor card :

You can connect 16 sensor inputs to the system.
The pin contacts can be set to NO or NC in the
server software setup.


POS function

With the POS function, you can display and save the transaction data of a POS system and its video pictures. The data is shown on the live video screen and can be analysed and saved via the playback screen. The format used is Excel.


Connecting the POS box



- POS to DVR : Connection between POS box and surveillance system (9 pin RS232C)
- IN / OUT : RS485 connection to or from another POS box
- DC+12 : Power supply 12V DC / 500 mA



- RS-232C : RS232C input signal from POS system (direct link) and surveillance system (9 pin RS232C)
- PARALLEL : Parallel connection from POS system




- PARALLEL : Parallel connection POS to other device
- RS-232C : RS232C output signal from POS box (Cross-Link)

POS function

Setting up the POS box

The following switch positions are shown on the base of the POS box :

SW1	1	2	3	4	5
	Other POS Box		MULTI POS	INPUT	OUTPUT
ON	Terminal ON		Terminal ON	PARALLEL	MULTIPOS
OFF	Terminal OFF		Terminal OFF	RS-232C	POS




	SW2	SW3	SW4
No	POS ID	POS SPEED	DVR SPEED
0	0	1200	9600
1	1	2400	14400
2	2	4800	19200
3	3	9600	38400
4	4	14400	57600
5	5	19200	115200
6	6	38400	128000
7	7	57600	X
8	8	115200	X
9	X	128000	X


POS function

Setup in the DVR software

The POS screen opens.



Click [Setup].



Set the correct communication parameters of the COM port. [Delay Time] sets the delay time for displaying the data of each article after entry in the POS system. [Wait Time] defines the delay time for the transmission from the POS system to the surveillance system for the accounting of all articles.

Select a camera that you want to associate with a specific POS ID. Enter the connection data and the type of POS system. Then close the window.

POS function


Analyzing transaction data

The POS data is automatically displayed in the video picture of the respective camera. To analyze the data, Change to the POS screen under [Search / POS].

The transaction data is shown on the left with date and time.

Click a data row : the video screen shows the associated video picture. Play back the video data using the Buttons in the playback bar. If necessary, you can save the video data in the playback screen as described Above.

You can search for specific data via the search mask.



The screenshot shows a search mask dialog box with a title bar containing 'Setup', 'Excel', and 'Close' buttons. The main area contains the following fields and controls:

- Channel:** A dropdown menu with the text '-----Select Channel-----' and a downward arrow.
- Start Time:** Two stacked input fields. The top field contains 'February 21, 2005' and the bottom field contains '1:01:53 AM'. Both have downward arrows.
- End Time:** Two stacked input fields. The top field contains 'February 22, 2005' and the bottom field contains '1:01:53 AM'. Both have downward arrows.
- Data:** A single-line text input field.
- Search:** A large rectangular button on the right side of the dialog.

Define a channel and period for the search. Under [Search string/Data], enter the text to be searched for (e.g., article name, assistant). Click [Search]. All found data is shown in the list on the left.



You can export the data in Excel format. Excel must first be installed in the surveillance system.
(not part of the scope of delivery)

How to make '.avi' CD from recorded images (Windows XP from Search menu)

Before you start these procedures, you have to make sure that CD recording is enabled from Windows XP.


To find out, follow the steps below.

1. "Power Off" the DVR software to go to the Windows XP desktop.




2. Double click on 'My Computer'

3. Right click on CD-RW drive (X:).



4. Click on 'Properties' and go to 'Recording' tab.
5. On 'Recording' tab, make sure there is a check mark on check box for 'Enable CD recording on this drive'




6. Click on 'OK' to exit from CD-RW Drive properties.

Note: Once you confirm or configure, you do not have to follow these procedure anymore.


After it is confirmed, put a blank CD into the CD-RW Drive and follow the steps below.

Steps:

1. From the DVRS software screen, click on 'SEARCH'.




2. Select the cameras and date.




NOTE: The dates shown in yellow indicate that the images of those dates are currently available in your hard drive.

3. By click and hold on vertical red line, move the red line to set as starting point of image that need to be burn on CD.




OR


You could set the specific hours and minutes by clicking up or down arrows.




4. Click on '+FUNCTION' and click on 'AVI'




5. Click on 'Save File...' to locate CD-RW drive and specify the file name.




Click on down arrow.



Locate 'CD-RW Drive'




Specify the file name on 'File name:' field.





then, click on 'Save'

6. Click on 'GO!!!' to start record.



NOTE: The recording images will display on screen and you can stop recording anytime by click on 'Stop saving AVI file'.

7. After AVI file is created successfully, click on 'OK' and click on 'Burning CD'.



8. Give the name for CD (by default it shows date) and click 'next' to start burning.

